



RESISTIVE WATER LOAD

Resistive water load is used to keep the fault current under check. This ensures that whenever there is a flashover or a failure in the sample.

The load acts as a bottleneck limiting the amount of fault current generated does ensuring safety and long liberty of the equipment and prevention of sample from a total burnout. This also ensures prevention of any damage around the faulty sample.

